



RECOMMENDATIONS USING HERKULIT TOP WITH LIN-PRO SPRINKLING CARRIER

Art. No 1205-1214
Page 1 (1)
[page 33]

Depending on that Herkulit Top contains a special cement is it possible to apply Herkulit later then other dry shakes.



- 1.) Apply the concrete base as evenly as possible. Less water in concrete reduce the colour differences in the surface layer.
- 2.) When you are able to walk on the surface and the "foot mark/print" is approx 1 mm, its time to apply the Herkulit. While applying this late, - will also avoid tire marks from the sprinkling carrier.
- 3.) Power float the surface in both direction with a disc before applying Herkulit, to avoid having residues on the top where the Herkulit is applied.
- 4.) Apply the Herkulit evenly over the surface, let it absorb water from the concrete base.
- 5.) After it has absorbed and started hardening, and when its suitable to start begin the power floating with disc at least 5-6 times in both direction. Consider using Allen composite pans.
- 6.) Then power trowel the surface with finishing blades, also in both directions at least 3-4 times.
- 7.) Directly after the towelling is made apply the Lindolit (water based) with the consumption of 1 litre (concentrate) to approx 17 m² or Lindolit S (solvent based) with the consumption of 1 litre to approx. 8-10 m².
- 8.) On the following morning, while using Lindolit waterbased, apply a lot of water and cover the hole surface with plastic film and let it stay there for at least 14 days.
- 9.) If and when a building cleaning will be made, its preferable to clean with Lino Floor wash using a scrubber dryer machine (scrubs and vacuums) with a black (safir) scouring nylon. With the consumption of 5 litre to 10 litre of water (0,05 litre/m²). This will also give an impregnation and final protection and also increase the surface shineness!